# MOTION click™

1. Introduction

MOTION click™ is a simple solution for adding an infrared motion detector—sensitive only to live bodies—to your design. It carries a PIR500B Pyroelectric motion sensor connected to a BISS0001 infrared sensor controller IC. Onboard potentiometer enables you to calibrate the sensor for distance. The board also features a photo resistor that enables you to set the sensor to work only at night. MOTION click™ communicates with the target board through **mikroBUS™** INT (out) and RST lines. It uses a 3.3V power supply.

2. Soldering the headers

Before using your click™ board, make sure to solder 1x8 male headers to both left and right side of the board. Two 1x8 male headers are included with the board in the package.

❶

❷

Turn the board upside down so that the bottom side is facing you upwards. Place shorter pins of the header into the appropriate soldering pads.

❸

Turn the board upward again. Make sure to align the headers so that they are perpendicular to the board, then solder the pins carefully.

3. Plugging the board in

Once you have soldered the headers your board is ready to be placed into the desired mikroBUS™ socket. Make sure to align the cut in the lower-right part of the board with the markings on the silkscreen at the mikroBUS™ socket. If all the pins are aligned correctly, push the board all the way into the socket.

4. Essential features

MOTION click™ is ideal for alarm systems, light switch controllers, and similar systems where human presence needs to be detected. The pyroelectric motion sensor generates a voltage when exposed to infrared radiation emitted by live bodies (the white plastic Flesner lens covering the sensor filters visible light). The BISS001 IC processes the signal and sends an interrupt to the MCU. To set up the detecting range of the sensor (up to 4 meters), use the onboard potentiometer. You can also activate and deactivate the sensor through the mikroBUS™ RST pin.

click™
BOARD

www.mikroe.com

5. MOTION click™ board schematic

MODE

OUTPUT

MIKROBUS DEVICE CONN.

AN	PWM
RST	INT
CS	TX
SCK	RX
MISO	SCL
MOSI	SDA
+3.3V	+5V
GND	GND

BISS0001

1	A	1OUT	16
2	V0	1IN-	15
3	RR1	1IN+	14
4	RC1	2IN-	13
5	RC2	2OUT	12
6	RR2	VDD	11
7	VSS	IB	10
8	VRF	VC	9

PIR Sensor

D
S
G

VCC VCC VCC VCC VCC VCC

C2 100nF
E1 22uF

R13 10K

R1 47K
C1 10nF
R2 10K
R3 15K

C3 10nF
C4 10nF

R4 1M

P1 1M
C5 10nF
R5 470K
R6 10K
E2 10uF

R7 1M
C6 10nF
R8 15K
E3 10uF
E4 10uF

R9 10
R11 1M
R10 1K
LD1
M1

J1E
VCC VCC
R12 1M
LDR

>0.2V Enable
<0.2V Disable

GND

6. Photo resistor

7. Code examples

Once you have done all the necessary preparations, it's time to get your click™ board up and running. We have provided examples for mikroC™, mikroBasic™ and mikroPascal™ compilers on our **Libstock** website. Just download them and you are ready to start.

LIBSTOCK .com

8. Support

MikroElektronika offers **free tech support (www.mikroe.com/support)** until the end of the product's lifetime, so if something goes wrong, we're ready and willing to help!

MikroElektronika
DEVELOPMENT TOOLS | COMPILERS | BOOKS